INSTALLATION INSTRUCTIONS 66 30344

FOR BALL BEARING IDLER ARM KIT

Hold idler arm "A" in vise with threaded bracket

arm until shoulder of the sleeve

bottoms against on the idler


Thread bearing mounting sleeve "B"


the shoulder of the idler arm. Be certain to lock

Remove the idler arm and frame bracket from the

car and clean thoroughly.

BRACKET END





as shown in view "D" with

Install lock plate "C" over mounting steeve "B"

- Pack ball thrust bearing install over mounting sleeve "B" with closed side grease and
- NOTE: A Moly-desulphide base grease is recommended for all lubrication.
- 6. Install flat washer "F" on mounting sleeve "B".
- Install frame as shown in illustration. bracket over mounting sleeve "B",
- Install flat washer "F" against trame bracket. over mounting sleeve "B"
- Pack ball thrust bearing "E" with grease and of bearing toward the frame bracket. înstall over mounting sleeve "B" with open side
- Install spacer washer "F".
- 11. Thread slotted nut "G" onto mounting sleeve "B" using a torque wrench, tighten nut to 20-25 ft. until all play is removed from idler arm, then
- If slot in nut is not in alignment with cotter pin hole in mounting sleeve "B", tighten nut "G" further until alignment is reached
- hole in mounting sleeve "B" Thread special curved cotter pin "H" through the and through slot in
- 14. Install grease fitting "J" through hole in cotter spread coffer \min 'H'' as shown in views 'K'' and ''L''. pin 'H'' and into mounting sleeve 'B':
- Lubricate at fitting.

16. 5.

- Remove assembly from vise, then place other end of idler arm in vise with threaded end up
- Assemble and lubricate parts as shown in center link illustration, using the bracket 9

