

# Installation Instructions for 50612

## BB-Chevy Low-Mount Alternator Kit

For Alternators: 555-10160, 358-2001, 358-2007 & 358-2009

Description	QTY	10160	2001/2007/2009
Bracket - Alt Mount - BBC - LH/RH - Lrg	1	X	X
Bracket - Alt Mount - BBC - LH/RH - Sml	1	X	X
Bracket - Alt Mount - BBC - LH/RH - Spacer	1	X	X
Spacer - 2.000"	2	X	X
7/16"-14 x 3-3/4" Bolt	2	X	X
3/8"-16 x 3" Bolt	1	X	X
5/16"-18 x 1" Bolt	1	X	X
7/16" Lock Washer	2	X	X
7/16" Flat Washers	2	X	X
3/8" Lock Washers	1	X	X
3/8" Lock Nut	1	X	X
5/16" Flat Washers	1	X	X

