

Installation Instructions for 60940 Multi-Fit Block Plate

Preparation for Automatic Transmissions: (AOD, C4, C6)

1. Remove the bottom section of the block plate along the perforated line using a hacksaw.
2. Remove any sharp edges or burrs with a file.

Preparation for 164-tooth Flywheel:

1. Remove the section of the block plate along the perforated line at the starter location using a hacksaw.
2. Remove any sharp edges or burrs with a file.

Install the block plate onto the dowel pins in the block.



1-800-345-4545 jeps.com