

## ***Installation Instructions for 70505 JEGS Quiet Ride Ultra Wire Harness Tape Kit – Self Adhesive***

### **TAPE INSTALLATION INSTRUCTIONS:**

1. Cut and place tape over wire harness or cable securing it to the vehicle or trim surface (Do not remove clear vinyl backing).
2. Press tape firmly into all of the contoured surfaces to prevent “bridging”.
3. **DO NOT USE TAPE TO INSTALL THE QUIET RIDE ULTRA SHEETS. IT IS ONLY TO BE USED TO SECURE WIRES TO PREVENT MOVEMENT AND SUBSEQUENT NOISE.**

