

Installation Instructions for 97005 G8 Fuse Box Cover

Applying vinyl graphics:

Step 1: Using the "hinge technique" use masking tape to hold the transfer in the desired position.



Step 2: "hinge" the transfer upward and peel the film from the bottom side.



Step 3: Starting from the taped edge, use a squeegee to apply the transfer. Work from top to bottom to avoid air bubbles.



Step 4: Slowly peel the top film from the cover.



IMPORTANT: When cleaning, always use extra care around vinyl graphics to prevent lifting.

Applying fuse box cover:

IMPORTANT: All components must be at least 65 degrees F for the adhesive to be effective.

Step 1: Use the supplied cleaning pad to thoroughly clean the plastic lid of the fuse relay center cover on your car.

Step 2: Remove the protective film from the two-sided tape on the back of your new cover.

Step 3: Align the cover as shown below so the reveal is uniform on the top, bottom and motor side of the cover. The gap on the outboard side as shown is intentional for adequate hood clearance.

Step 4: Press firmly to insure good adhesion.

