

## Installation Instructions for 154050 & 154055 Carburetor Heat Shield

**NOTE:** Carburetor must sit flat on the heat shields: in some cases, the aluminum plates may have to be notched or filed to clear carburetor linkage, fast idle cams and related components.

**WARNING:** Before starting engine or operating vehicle, actuate the accelerator pedal over its full range of travel; the primaries and secondaries must be fully opened then spring close with the operation of the gas pedal only. The linkage must be free moving with no obstructions, sticking or binding. Be sure to use a good return spring that is securely attached for a positive throttle return.

The large heat shield plate may have to be trimmed on some applications for choke linkage clearance. The template to the right may help if the trimming operation is necessary. Be sure to print this instruction sheet at full scale or actual size.

