

Installation Instructions for 40689 Steel Distributor Hold Down

Note: The position of the Billet Hold Down Clamp is imperative to its operation. The end points of the clamp must seat squarely on the intake manifold as well as the distributor collar.

Installation Instructions:

1. Install the mounting stud into the intake manifold.
2. Install the steel clamp, flat washer, lock washer and the nut on the mounting stud.
3. Position the clamp on the distributor collar and tighten the nut. The illustration below shows the correct installation of the clamp. If the clamp is installed at an excessive angle and the end points of the clamp do not properly seat, the clamp will not tighten properly.

