

## ***Installation Instructions for 50128 Valve Cover Baffle Kit***

### **Installation Instructions:**

1. Decide the desired location in the valve cover you want your baffle to be, making sure to check all valve train clearances. Using a center punch and hammer, indent the valve cover where you want to drill.
2. Making sure to lock the valve covers in place, when drilling, and wear safety glasses. Drill a 1-3/8" hole for the baffle, make sure to file or remove any extra metal or burrs around the hole.
3. Place the O-Ring onto the baffle at the base of the threads.
4. Install the baffle through your valve cover, with the hex head side of the baffle inside the valve cover, and the threads of the baffle coming through the top of the valve cover.
5. Install the washer, and then the nut. Be sure not to over tighten the nut. You can now put whatever breather you want into the baffle, as long as it fits a 1-1/4" grommet.



**1-800-345-4545 [jeps.com](http://jeps.com)**