

Installation Instructions for 50600
SB-Chevy Mid-Mount Alternator Kit
 For Alternators: 555-10172 & 358-2002

Description	QTY	10172	2002
Bracket - Alt Mount - SBC Mid - LH Lrg	1	X	X
Bracket - Alt Mount - SBC Mid - LH Sml	1	X	X
Spacer - 1.250"	2		A
Spacer - 0.875"	2		B
Spacer - 2.000"	2	C	
Spacer - 0.125"	2	D	
3/8"-16 x 3-3/4" Bolt	2	X	X
3/8"-16 x 2-1/2" Bolt	1	X	X
M8 x 35 Bolt	1	X	X
3/8" Flat Washers	2	X	X
3/8" Lock Washers	2	X	X
5/16" Flat Washers	2	X	X
M8 Nut	1	X	X
3/8" Nylock Nut	1	X	X

