

Installation Instructions for 511105 Mustang Coolant Hose Kit

Installation Instructions:

1. Remove the lower radiator hose from the water pump and let drain.
2. Remove the lower radiator hose from the vehicle.
3. Match up your new lower radiator hose to the original and install your new lower radiator hose onto the vehicle.
4. Remove the upper radiator hose from the radiator and let drain.
5. Remove the upper radiator hose from the vehicle.
6. Match up your new upper radiator hose to the original. Remove the protective cover from the upper radiator hose that originally was directly above the alternator and install it onto the new upper radiator hose in the same location. Install your new upper radiator hose onto the vehicle.
7. Remove the front heater core hose from the water pump just below the thermostat housing and let drain.
8. Remove the front heater core hose from the vehicle.
9. Match up your new front heater core hose to the original and install your new front heater core hose onto the vehicle.
10. Remove the thermostat bypass hose from the thermostat housing and let drain.
11. Remove the thermostat bypass hose from the vehicle.
12. Match up your new thermostat bypass hose to the original and install your new thermostat bypass hose onto the vehicle.
13. Remove the two rear heater core hoses from the rear of the engine just behind the EGR valve and let drain.
14. Remove the two rear heater core hoses from the vehicle.
15. Match up your two new rear heater core hoses to the original and install your new rear heater core hoses onto the vehicle.
16. Refer to the vehicle service and repair manual for filling of the coolant system.



1-800-345-4545 jeps.com