

# Installation Instructions for 51700 Engine Oil Cooler

## Mounting:

The coil may be mounted vertically or horizontally. If mounting in front or behind the radiator leave a 1/4" air gap between the two. Assemble mounting hardware as shown in illustrations below:



## Installation:

Install fittings in the cooler coil (Figure 1). Coil fitting size is a 1/2" FPT **Always use a 1" backup wrench on the coil** (See Fig. 1). Seal threads with JEGS thread sealing #555-28011. **DO NOT OVERTIGHTEN** (maximum torque is 28 ft/lbs.)




FIGURE 1

## Recommended Items (Not Included)

### Sandwich Adapter:

<u>Part Number</u>	<u>Application</u>	<u>Port Size</u>	<u>Description</u>
51710	AMC, Some Jeep with 2-3/4" Dia. O-Ring	3/8" FPT	3/8" NPT to 1/2" Hose
51711	GM/Chevy with 3-1/2" O-Ring	1/2" FPT	1/2" NPT to 1/2" Hose
51712	Ford, Chrysler, Some Imports	3/8" FPT	3/8" NPT to 1/2" Hose

### Cooler Fittings:

15977	Rubber Hose	1/2" NPT to 1/2" Hose Barb, Straight Brass
15978	Rubber Hose	1/2" NPT to 1/2" Hose Barb, 90° Brass

### Hose:

51720	Standard Installation	1/2" x 12' Rubber Hose
JEGS Pro Flo 200	Premium Installation	Stainless Braided
JEGS Pro Flo 350	Premium Installation	Nylon Braided



1-800-345-4545 [jegs.com](http://jegs.com)