

## ***Installation Instructions for 52270 Universal Chrome Dipstick***

**NOTE:** Prior to installing the Brass NPT Ferrule on the bottom of the dipstick tube you may find it necessary to deburr this area as the manufacturing and chroming process may leave a slight burr. A small amount of pressure, such as tapping, may also be used to get the ferrule past any burr that may exist.



**1-800-345-4545 [jeps.com](http://jeps.com)**