

Installation Instructions for 55030 Dragster LED Tail Light

Installation Instructions:

1. Insert a 3/16" slotted screwdriver into one end of the tail light just under the yellow seal. Slowly twist the screwdriver to release the LED lens assembly. FIGURE 1
2. Notice the battery orientation markings on the bottom of the LED assembly in FIGURE 2. The batteries must install in opposite directions for the tail light to work properly.
3. Shown in FIGURE 2; Notice one side has flat terminals and the other spring type.
4. ALWAYS install batteries flat terminal first as shown in FIGURE 3.



FIGURE 1



FIGURE 2



FIGURE 3