

# Installation Instructions for 60204 & 60208 CO2 Micro Bottle Switch

Available for: 2.5# and 10oz. bottles

## Installation Instructions:

1. With the bottle valve in the fully closed position, hold the knob in the closed position and remove the nylon lock nut from the top of the bottle valve and remove the knob.
2. Screw the #8 x 3/16" SHCS into the knob bracket.
3. Slide the knob bracket over the knob shaft so that it is fully seated at the bottom of the hex.
4. Reinstall the knob and nylon lock nut using a drop of "blue" Loctite on the threads.
5. Install the micro switch onto the bottle bracket using two #4 x 1/2" SHCS.
6. Install the bottle bracket onto the bottle using two #8 x 3/4" SHCS and clock it to the desired location making sure the bracket is horizontally level on the bottle.
7. It may be necessary to adjust the #8 x 3/16" SHCS on the knob bracket in or out to get desired contact on the micro switch.

