

Installation Instructions for 60390 to 60392 & 60395 Transmission Overflow Tank

1. The overflow tank mounts to the transmission pan under the torque converter.
 2. Connect the overflow tank inlet to the transmission vent using the supplied hardware.
 3. We recommend the use of a liquid Teflon sealant on fittings to reduce the risk of leaks.
- Note:** GM stock Powerglide case with plastic push in vent must be tapped to accept 1/8" NPT fitting.

