

Installation Instructions for 64930, 64932, 64934, 64936 Coil-Over Shock Set-Up Tool

1. First you must measure between the two locating points where the coil-over shock will be mounted.
2. Once measured, adjust the rod ends in or out depending on your choice of ride height and tighten the adjuster nuts.
3. When that is complete, place the tool where the coil-over shock will be mounted using 1/2" hardware (not included). If not at desired height once installed, just loosen up the adjuster nuts and turn the tool left or right until the desired ride height is achieved.



1-800-345-4545 jeps.com