

Installation Instructions for 80027 Jack Skid Plate

1. Remove the rear wheels of the jack by using a 19mm socket.
2. Place the jack onto the jack skid plate by inserting the front axle into the slots.
3. Once in position, center the jack onto the skid plate.
4. Fasten the jack to the skid plate using the supplied hardware. Tighten the hardware by using an 11/16" socket and 11/16" wrench.
5. Check the jack for full working operation.



1-800-345-4545 jeps.com