

Installation Instructions for 81720 Metal Shot Bag

Metal Shot Bag Filling Guidelines

We recommend filling shot bags with 12lbs. sand, or 42lbs. of 8 or #9 lead shot. Lead shot is available at most sporting good stores (shot) or home improvement centers (sand). Do not use steel shot! Silica or play sand can be used as an alternate.

Fill Instructions:

Each bag has a Velcro opening seam located in the riser band of the bag. A funnel can be inserted into the opening and sand or lead shot inserted. Observe the weight recommendations as to how much to fill. This method will also work in reverse when you will want to replace sand over time. Shake out as much as possible and refill. If you choose sand it will be reduced to powder over time depending on use and requires refreshing. Leave room in the bag for the shot to displace during metal shaping or damage to the seams will occur.

Tips:

- Always deburr all edges of your sheets before working on the bag.
- Snip or trim all corners or sharp edges of your sheet; otherwise these edges tend to curl under and dig into the bag damaging the leather.
- If you cut or slice the bag surface, cut a small leather patch and use any glue that will bond to leather and liberally apply to the surface, clamp and allow to fully dry before use.



1-800-345-4545 jegs.com