

Installation Instructions for 97000 G8 Radiator Cover

Installation Instructions:

Step 1. Insert radiator cover by tilting the cover and engaging under the windshield washer fluid cap (blue cap). After the cover is under the blue cap, align with the four fastening holes.



Step 2. If necessary, Align the yellow coolant tank cap with the cut out in the radiator cover. Use supplied cable ties to align the coolant neck.



Step 3. Insert 4 push fasteners to secure the radiator cover. If the lip of the cover appears high in the front in the area near the blue cap, be sure the cover is not hooked under one of the protrusions on the windshield washer fill tube. Adjust if necessary.

To remove the cover, use a screw driver to pry up on the center "nail" of the fastener. It needs to pull upward about 1/2". Next, gently pry upward on the body of the fastener to remove it.

