

## ***Installation Instructions for 10308 Remote Starting Solenoid***

**WARNING!** This solenoid DOES NOT use suppression diodes. Use of this solenoid on vehicles with Engine Control Computers will result in permanent damage to the computer/processor.

### **Installation Instructions:**

1. Prevent nuts (A) from rotating during installation of cables.
2. For three wire installations, do not use "I" terminal.

