

Installation Instructions for 50210 Universal Engine Diaper

Installation Instructions:

1. Lay absorbent pad in bottom of engine diaper.
2. Fasten the engine diaper to the header mounting bolts as shown.
3. Pull straps tight making sure the engine diaper is clear of any exhaust and clear from the harmonic damper or any other moving parts.

