

Installation Instructions for 100800 Tunnel Ram Fuel Line Kit

Kit Includes:

- 1) **15110** 3/8" Y-Block
- 4) **100001** #6 Hose Ends
- 2) **100106** 3/8" NPT to #6
- 1) **100503** 9/16" -24 to #6 (2-piece kit)
- 1) **100910** 3-ft. #6 Hose

