

Installation Instructions for 70220

Sliding Seat Mount

Note: Requires use of 70225 Stationary Pedestal Mount

Kit Includes:

- | | |
|------------------------------|-----------------------------|
| 1) Slide Rail with Handle | 4) 5/16" Threaded Lock Nuts |
| 1) Slide Rail without Handle | 4) 3/8" x 1" SHCS Bolts |
| 1) Cross Wire | |
| 4) Cone Washers | |

NOTE: DO NOT TIGHTEN ANY BOLTS UNTIL THE LAST STEP!

1. Place slider brackets parallel to each other and position cross wire as shown in diagram.
2. Place cone washers between the slider brackets and seat. Thread the 3/8"-16 SHCS bolts through the slider brackets and cone washers into the mounting inserts in the seat bottom.
3. Place the seat in the desired location in the vehicle and mark the location of the two front mounting studs.
4. Measure back 11" from the marks made for the front mounting studs and mark locations for the rear mounting studs.
5. Drill four 11/32" holes in the locations determined in steps 3 and 4.
6. Place the seat in the vehicle and position the 4 mounting studs on the slider bracket through the 4 holes drilled in step 6.
7. Thread the 5/16" lock nuts and lock washers to the mounting studs and secure the seat to the vehicle.

