

Installation Instructions for 80061 Engine Stand Tool Tray

Installation Instructions:

1. Place tool tray at desired height on rear of engine stand and drill one 7/32" hole through tray and engine stand.
2. Install one 1/4" self tapping screw with flat washer and tighten.
3. Place bracket under tool tray and flush against engine stand. Using the bracket as a template mark and drill two 7/32" holes through engine stand.
4. Install two 1/4" self tapping screws with flat washers and tighten.
5. Using the bracket as a template mark the location of the two threaded holes on the underside of the tool tray, making sure the tool tray is level.
6. Remove the tool tray from the engine stand by removing the screw from step 2 above and drill two 9/32" holes in the tool tray.
7. Reinstall the tool tray on the engine stand using the supplied threaded knobs and 1/4" self tapping screw from step 2 above.



1-800-345-4545 jeps.com