



PART NO. 30044 & 30045

1996-97 LT1 Camaro/Firebird
Retro-Fit "Loud Mouth" Kit
1993-95 LT1 Camaro/Firebird
Retro-Fit "Loudmouth" Kit

PACKING LIST

<u>Item #</u>	<u>Check</u>	<u>Quantity</u>	<u>Part Number</u>	<u>Description</u>
1	<input type="checkbox"/>	1	310301491	Rubber Isolator
2	<input type="checkbox"/>	1	10407350	Hanger Driver Side
3	<input type="checkbox"/>	1	10272958	Bracket Passenger Side
4	<input type="checkbox"/>	1	11516071	Nut Passenger Side
5	<input type="checkbox"/>	1	11500323	Washer Passenger Side
6	<input type="checkbox"/>	1	310012785	Pipe Adapter, Intermediate Pipe*
7	<input type="checkbox"/>	1	*****	Instructions

* Part only comes with Part #30045

Warning: SLP recommends allowing the vehicle to cool (not running) for five hours before beginning the installation. Exhaust components and can be extremely HOT and could cause severe burns if it is not allowed to cool. SLP also recommends wearing safety glasses for the complete installation. Refer to GM service manuals for further pictures or specifications.

Note: This Kit is a Retro-Fit for the LS1 Loud Mouth Exhaust System (SLP P/N 31039 or P/N 31039A) Follow P/N 31039 or P/N 31039A instructions to fully complete the retro-fit installation.

INSTALLATION INSTRUCTIONS

1. Follow steps 1 and 2 on instructions for P/N 31039 or P/N 31039A then follow with step 2 below.
2. Replace passenger side bracket with new SLP Performance Parts bracket by sliding it into the rubber holder on the passenger side. (Use the new washer and nut supplied by SLP when installing the new exhaust system.)
3. Remove the driver side hanger bolts, hanger and isolator and replace using the new SLP hanger with the stock bolts, and the new isolator.
4. Bolt pipe adapter to the back of the catalytic converter using the 3" ball flange. (follow this instruction only for P/N 30045)
5. Continue this installation with step 3 on instructions for P/N 31039 or P/N 31039A.