



350 S. St. Charles St. Jasper, In. 47546
Ph. 812.482.2932 Fax 812.634.6632
www.ridetech.com

Part # 11284499
65-70 Impala Rear Lower StrongArms
For use w/ CoolRide

Components:

2	90001027	Lower arm – WW 22.5"
4	90001085	Poly bushing half
2	90001089	Poly bushing half (Rear)
2	90001086	Poly bushing half (Front)
2	90000722	Inner bushing sleeve - 2.625" long x .625" I.D x .75" O.D. (Rear)
2	90000467	Inner bushing sleeve - 2.5" long x .625" I.D. x .75" O.D. (Front)
2	90001092	Tube of Lithium grease

Hardware:

4	99621006	5/8" x 3 3/4" SAE Gr. 8 bolt	Upper and lower arms
4	99632002	5/8" SAE Nylok jam nut	Upper and lower arms/panhard bar stud

STRONG ARMS™

by Air Ride Technologies

Installation Instructions



1. Clean the bushing surfaces on the frame and axle brackets. Lubricate with the lithium grease supplied.
2. Fasten the StrongArm to the frame and axle using the 5/8" x 3 3/4" bolts and Nylok jam nuts supplied.
3. Fasten the air spring to the lower arm using a 3/8" x 3/4" bolt, flat washer and lock washer supplied w/ the air spring kit.

ridetech
Air Ride Technologies