



350 S. St. Charles St. Jasper, In. 47546
Ph. 812.482.2932 Fax 812.634.6632

www.ridetech.com

Part # 11306698
67-70 Impala Rear Upper StrongArm Kit

Upper Arm Components:

1	90001117	Upper StrongArm – C-C 10.00"
1	90001589	Kevlar lined Heim end - .75" thread x .625" I.D.
1	99752004	3/4"-16 SAE jam nut
2	90002066	Aluminum bearing spacer
1	90001085	Poly busing half
1	90001089	Poly busing half
1	90000722	Inner bushing sleeve - 2.625" long x .625" I.D x .75" O.D.

Hardware:

2	99621006	5/8" x 3 3/4" SAE Gr. 8 bolt	Upper arm
2	99632002	5/8" SAE Nylok jam nut	Upper arm

STRONG ARMS™

by Air Ride Technologies

Installation Instructions



1. Replace the factory upper trailing arm with the StrongArms. 5/8" x 3 3/4" bolts and Nylok jam nuts are supplied to replace the factory hardware. An aluminum spacer will be installed on each side of the Heim end.

Note: Some cars may have two upper arms. In this case you will need to order a second upper arm, part # 11296698

ridetechnologies
Air Ride Technologies