

Installation Instructions TOE-IN ALIGNMENT PLATES

*Please read these instructions completely
BEFORE using your using your parts!*

Your *HEIDTS* Hot Rod Shop TOE-IN ALIGNMENT PLATES
contains the following items:

- 2) Toe-In Alignment Plates
- 4) Rubber Edge Strips
- 2) Tape Measures

To use your new *HEIDTS* Hot Rod Shop Toe-In Alignment Plates first install the four rubber edge strips on the bottom edges of the Plates. These keep the Plates from sliding out, away from the tires. Next, place one Plate against the outside sidewall of each front tire. Seat them tightly against the tires so accurate measurements can be taken. String the Tape Measures from one plate to the other, sliding them into the slots in the ends of the Plates. Now gently but firmly pull and hold both tapes to eliminate any slack in them, then look at the dimensions on both Tape Measures. The difference in the two dimensions is your toe-in, or toe-out, if the front dimension is larger than the rear. You can now compare and set the actual toe-in dimension to the specifications for your front suspension.

