

INSTALLATION INSTRUCTIONS FOR

DynoMax ULTRA FLO WELDED KIT: 39533

2015 Ford Mustang GT 5.0L V8 - Stainless Steel Dual Mufflers - Axle-Back System



2701 N. Dettman Rd.
Jackson, MI 49201

DANGER WARNING: SHOULD THE PURCHASER DECIDE TO INSTALL THIS EXHAUST PRODUCT AT HOME, BE WARNED THAT LIGHT DUTY TRUCK "BUMPER" JACKS ARE INTENDED FOR EMERGENCY USE ONLY. THE USE OF FRAME CONTACT JACK STANDS IS HIGHLY RECOMMENDED TO MINIMIZE ACCIDENTAL DROPPING OF A VEHICLE DURING THE INSTALLATION PROCESS. FAILURE TO HEED THIS WARNING COULD RESULT IN SEVERE INJURY OR DEATH.

NOTE: Please read all instructions before beginning the installation.

1. Hold each Dynomax Ultra Flo Welded muffler (**52558** passenger side and **52559** driver side) underneath the OE mufflers and mark where the OE mufflers /pipes will be cut-off. Be sure to allow length to over-lap the Dynomax mufflers onto the OE pipes.
2. Remove the original mufflers. Slip a 2½" band clamp over the inlet pipe of each Dynomax muffler and install. Be sure to insert the rod hanger in the rubber hanger on each muffler.
3. Install Dynomax stainless steel tip **36505** on each muffler outlet connection.

4. Beginning at the inlet end, position the mufflers and tips and tighten all clamps.
5. Start the vehicle and check for exhaust leaks. Retighten and position as required.

KIT CONTAINS:

- (1) 52558 Muffler, RH
- (1) 52559 Muffler, LH
- (2) 36505 SS Tip w/3" Clamp
- (2) 36438 2½" Band Clamp
- (1) Instruction Sheet

39533 SYSTEM DIAGRAM

