

**INSTALLATION INSTRUCTIONS FOR
DYNOMAX VT MUFFLER PROFESSIONAL
INSTALLERS DUAL KIT: 88345**

2010-09 Dodge Ram Pickups, 2 / 4 W.D.



2701 N. Dettman Rd.
Jackson, MI 49201

DANGER WARNING: SHOULD THE PURCHASER DECIDE TO INSTALL ANY EXHAUST PRODUCT AT HOME, BE WARNED THAT PASSENGER CAR OR LIGHT DUTY TRUCK/VAN "BUMPER" JACKS ARE INTENDED FOR EMERGENCY USE ONLY. THE USE OF FRAME CONTACT JACK STANDS IN CONJUNCTION WITH A FLOOR JACK AS MAIN SUPPORT IS HIGHLY RECOMMENDED TO MINIMIZE ACCIDENTAL DROPPING OF A VEHICLE DURING THE INSTALLATION PROCESS.

NOTE: Please read all instructions before starting any work.

1. Remove the OE muffler/tail pipe assembly. Use WD-40 or a similar product to lubricate and help remove the metal rod hangers from the rubber isolators.
2. Install DynoMax VT muffler **17963**. Install hangers as required.
3. Install RH over-axle pipe **65066** and LH over-axle pipe **64344**. Fabricate and/or install hangers as required.

4. The rear tail pipes **64343 & 64345** will require modification for final installation. These pipes can be bent and cut-off for side exit or cut-off for rear exit. Fabricate and/or install hangers as required.
5. Install SS tips **36486** onto both tail pipes using the band clamps provided.

KIT CONTAINS:

- (1) 17963 VT MUFFLER
- (1) 65066 PIPE
- (1) 64344 PIPE
- (1) 64343 PIPE
- (1) 64345 PIPE
- (2) 36486 SS TIPS w/2½" BAND CLAMPs
- (4) 2½" BAND CLAMPs
- (1) 3" BAND CLAMP
- (1) 711407 INSTRUCTION SHEET

88345 SYSTEM DIAGRAM

