



CHROME TRIM INSTALLATION SHEET

Congratulations on your purchase of a high quality PUTCO product. Should you need any application or technical assistance feel free to call us at:

1-800-247-3974

Monday-Friday 8:00 a.m.- 5:00 p.m. (Central Standard Time)

Contact your PUTCO dealer for other quality accessories.

PUTCO Inc. - 216 West First Street - Story City, Iowa 50248

PLEASE READ ALL INSTRUCTIONS BEFORE INSTALLATION AND TO CHECK TO SEE THAT ALL PARTS ARE INCLUDED.

Installation Instructions

1. Insure that the surface which the trim is to be applied is clean, dry and free of all oil, grease and wax. The application surface must also be warm, minimum temperature of 10°C (50°F)
2. Wash area with clean water and then dry. Wipe area a second time with a cloth moistened with rubbing alcohol to remove all oils and waxes. For best results when applying chrome trim to unpainted plastic parts, Primer Adhesion Promoter is recommended.
3. Determine exact location for trim piece on vehicle.
4. Remove protective film from adhesive strip, align carefully and then press firmly for 30 seconds to insure proper adhesion.

Instrucciones de Instalación:

1. Asegúrese que la superficie donde va a instalar el accesorio cromado esté limpia, seca y libre de cera, grasa o aceite. La superficie debe estar tibia, a una temperatura de por lo menos 10° C (50° F).
2. Lave el área de aplicación con agua limpia y seque. Limpie una vez más usando un trapo con alcohol para quitar todo residuo de cera o grasa. Para obtener mejores resultados, cuando aplique el accesorio cromado a una superficie de plástico sin pintar, utilice el Promotor de Adhesión Primario (Primer Adhesion Promoter).
3. Determine la ubicación exacta del accesorio cromado en el vehículo.
4. Retire la cubierta protectora de las cintas adhesivas, alinee cuidadosamente la pieza cromada en el lugar donde será colocado y presione firmemente por 30 segundos para asegurar una adhesión correcta.

Instructions d'installation

1. Assurer que la surface qui le mince va être appliqué s'est propre, sécher et libérer de tout pétrole, toute graisse et toute cire. La surface d'application doit être aussi temperature chaude et minimum de 10°C (50 F)
2. Laver le secteur avec l'eau propre et sécher alors. Essuyer le secteur un deuxième temps avec un tissu humidifié avec d'alcool pour enlever tous pétroles et toutes cires. Adhesion Promoter Primer est recommandé.
3. Déterminez l'emplacement exact pour la partie d'équilibre sur le véhicule.
4. Enlever le film protecteur de la bande adhésive, alignez soigneusement et appuyez alors fermement pendant 30 secondes pour assurer l'adhérence appropriée.

Note: PUTCO recommends applying a high quality automotive wax to maintain the original appearance on your new chrome trim.

LIMITED WARRANTY

Putco warrants its stainless steel and aluminum products against defects in workmanship and materials for as long as you own your vehicle. "Black powder-coated and chrome plated products have a one year warranty on the finished surface." Any defects resulting from faulty material or workmanship will be warranted by Putco and repaired or replaced at our discretion. Putco assumes no extra labor costs. Damages caused by freight carriers, improper installation, misuse, collision, or neglect will not be warranted by Putco. Putco requires the original receipt for any warranty claims.