



Installation Instructions
Front Bolt-On/Rugged Look Fender Flares
Ford Superduty F250/F350 (11-ON) FF836

Please read instructions entirely before installing this product.

Hardware Included	QTY
EXTRUSION	28ft
CLIP .6mm	10

Hardware Included	QTY
ALCOHOL TOWELETTE	4


Bolt Kit Included	QTY
ALLEN KEY BOLT	42
NUT	42

Ensure that both left and right hand Fender Flares suit the profile of the vehicle. Note the areas where the Fender Flares come in contact with the vehicle. NOTE: Before fitting Fender Flares remove any moldings, strips or existing flares from the wheel arch. If there is a body side molding, mark where the molding is to be cut, alternatively the Fender Flare can be cut to go around the molding. Be sure to allow enough room for the extrusion.

FRONT FENDER FLARE INSTALLATION



STEP 5: Clean the body areas where the Fender Flares will make contact.



STEP 6: Remove all 5.5mm socket head screws and retain for installation of Fender Flares.

For models equipped with factory fender flares, removal of factory flares is required, please consult the vehicle service manual for factory fender flare removal.

For Technical Support/Warranty Information please call 800-757-7075
EGR Inc., 4000 East Greystone Drive, Ontario, CA 91761



Installation Instructions
Front Bolt-On/Rugged Look Fender Flares
Ford Superduty F250/F350 (11-ON)

FF836

REAR FENDER FLARE INSTALLATION



STEP 7: Place the Fender Flare onto the vehicle and fit into the correct position following the contours of the body. Ensure the slots in the part align with the holes in the fender from the previously removed 5.5mm socket head screws.





STEP 8: Reinstall the 5.5mm socket head screws through slots in the Fender Flare to the vehicle. Make sure the screws are securely engaged to the vehicle fender.

For Technical Support/Warranty Information please call 800-757-7075
EGR Inc., 4000 East Greystone Drive, Ontario, CA 91761



Installation Instructions
Front Bolt-On/Rugged Look Fender Flares
Ford Superduty F250/F350 (11-ON)

FF836



STEP 11: Clean the body areas where the Fender Flares will make contact. Use the supplied alcohol wipe.

For models equipped with factory fender flares, removal of factory flares is required, please consult the vehicle service manual for factory fender flare removal.

STEP 12: Place the Fender Flare onto the vehicle and fit into the correct position following the contours of the body. Use ten (10) of the .6mm clips (five 5 per side) to secure the Fender Flare to the body. Make sure the dimple in the clip securely attaches in the slot on the Fender Flare.



STEP 13: Double check the front and rear Fender Flares to make sure all bolts are tight and clips are securely fastened. Your installation is now complete. Do not use abrasive cleaners.

For Technical Support/Warranty Information please call 800-757-7075
EGR Inc., 4000 East Greystone Drive, Ontario, CA 91761