



**INSTALLATION INSTRUCTIONS**  
**PLEASE READ THE FOLLOWING INSTRUCTIONS BEFORE**  
**INSTALLING YOUR NEW AIR CLEANER**

**CATALOG #1236 and #4236**

**MODEL:** Pro-Flo/Elite Oval Air Cleaner - Single carb

**INSTALLATION INSTRUCTIONS:**

Install suitable air horn gasket and carburetor stud (not supplied) on carburetor and place air cleaner base over carburetor. Thread the special bracket on the carb stud until the two studs will protrude through the top of the air cleaner by about 1/2". Bracket must be positioned to clear carburetor choke linkage. Install filter and air cleaner lid, checking for clearance between the carb stud and lid. Trim carb stud if necessary.

For carburetors with tall bowl vent tubes, it may be necessary to purchase Edelbrock air cleaner spacer #8092. Vent tube to air cleaner clearance should be no less than 1/8".

**MAINTENANCE:**

This pre-oiled gauze element can be cleaned and re-oiled as needed to extend its filtering efficiency. Simply wash element in hot soapy water and allow to dry, then apply a light aerosol oil. Replacement filters (Edelbrock #1220) are available through your dealer.