INSTALLATION INSTRUCTIONS for Elite Breather, bolt-on top mounting CATALOG #4202 & #4212

INSTALLATION INSTRUCTIONS:

1. Using baffle plate bosses on inside of Elite Series valve covers as pilot holes, drill 11/32" holes completely through valve cover. Also enlarge baffle plate mounting holes.

NOTE: These breathers will not fit Elite Series valve covers #4244, #4246, #4247, or #4248.

- 2. Clean all chips and burrs from cover and plate.
- 3. Install grommet, baffle plate, and breather with bolts, nuts and washers supplied.

©1997 Edelbrock Corp.

Rev. 3/97