

Installation Instructions

Eibach Springs, Inc. • 264 Mariah Circle • Corona, California 92879-1751 • USA • Tech Support 800-222-8811 Ext 114



Pro-Kit- # 1591.140

Audi A3
2006

Kit Contents	Description	Part Number	Qty
	Front Spring	11-15-007-02-VA	2
	Rear Spring	11-15-007-01-HA	2
	Information Kit	EPAK	1
	Instructions	1591.140INST	1

NOTES: Read All Instructions Before Beginning Installation

- **Only qualified mechanics experienced in the installation and removal of suspension components should perform this installation.**
- **Use** of a hoist is highly recommended and will substantially reduce installation time.
- **Never work on or under a vehicle unless it is properly supported by safety stands.**
- **PRO KIT** springs are marked with a VA, for Front and a HA, for the Rear.
- **PRO KIT** springs should be installed with the **Eibach** Logo right side up. All original stock spring isolators, dampers and tubing should be retained from the stock springs and used when installing the springs.
- **After** installation, it is always important to inspect and adjust the following if necessary:
 - Wheel alignment such as camber, caster & toe
 - Tire and/or wheel fender clearance, when aftermarket tires and wheels are used.
 - Brake line clearance and attachments
 - Brake anti-locking and anti-skid system sensors

Tire Rotation: In order to increase the life of your tires, it is recommended to rotate your tires every 3,000 miles.

After installation, it will be necessary to perform a full vehicle alignment.

Additional Eibach Components Available For Your Car

Eibach Kits	Part Number	Description	Front	Rear
Sportline	4.8515	Performance Tuned Handling	2.0in	1.6in
Anti-Roll Kit	1591.320	Performance Tuned Handling	26.0 mm	23.0 mm

Bump Stop Trimming Instructions

Typical Bump-Stop
(Bump-Stop from your vehicle may have different shape)

