

FLOWMASTER™

FORCE II™

SYSTEM #17161

1987-91 CHEVY BLAZER/GMC JIMMY

350 ci , 4W.D.

04/13/01

Removal:

- 1) Using a hacksaw or sawsall, cut the stock tailpipe off at the rear of the muffler.
- 2) With a hacksaw or sawsall, cut the clamp/hanger that supports the tailpipe. (leaving the main bracket with rubber insulator on the vehicle) -remove the tailpipe.
- 3) With a 15mm wrench remove the clamp at the muffler to catalytic converter connection. Save the hanger which is supported by this clamp, it will be used with the Flowmaster system.
- 4) Separate the muffler from the catalytic converter. It may be necessary to heat the connection with a torch to loosen it. **USE EXTREME CAUTION.** Remove from under the vehicle.

Installation:

- 1) Slip pipe #26047 on to the back of the catalytic converter. Install one of the clamps provided, along with the stock hanger which was removed in step 3, and tighten lightly.
- 2) Raise muffler #53057 into position and connect to pipe #26047. Use a stand or box to support the muffler. Install one of the clamps provided, and tighten lightly.
- 3) Raise pipe #26048 into position over the axle and connect with rubber hanger and muffler outlet. Install one of the clamps provided, and tighten lightly.
- 4) Adjust the position of muffler and pipes to produce a satisfactory fit and adequate clearance. Keep suspension movement in mind.
- 5) Tighten all clamps down securely.

PACKING LIST

<u>QTY..</u>	<u>Part No.</u>	<u>Description</u>
(1)	26047	Inlet Pipe
(1)	53057	Muffler
(1)	26048	Tailpipe
(1)	PK145	Parts kit
(3)	3" Muffler Clamps	
(1)	Instruction sheet	

*FLOWMASTER FORCE II SYSTEM #17161
1987-91 CHEVROLET BLAZER/GMC JIMMY
350 C.I. ENGINE, 4 WD.*

