

**11518**  
**10-12 FORD**  
**MUSTANG BASE**



**11518**  
**10-12 FORD**  
**MUSTANG BASE**

---

## **10-12 FORD MUSTANG BASE**

### **Front Bumper Trim**

**TOOLS REQUIRED:**

Alcohol/Clean Rag

**PARTS LIST:**

1 T1 Series Bumper Trim Kit 2 Pc.

**Step 1**

Clean the area where the Trim will be installed with alcohol and a clean rag. Test fit the trim. Remove the plastic backing on the adhesive on the back of the Trim.

**Step 2**

Position the Trim on top of the factory bumper. Press on the Trim to ensure the adhesive backing adheres to the factory bumper openings.