

21172
07-12 GMC
YUKON



21172
07-12 GMC
YUKON

2007-12 GMC YUKON
BILLET OVERLAY (with Logo Cut-Out)

Recommended Tools:

Phillips Screwdriver
Slotted Screwdriver
7mm, 8mm, 10mm Socket

Parts List / Hardware:

1 Billet Insert
4 6-32 x 2 Machine Screws
4 #8 U-Nuts
2 ¾" J Hooks
2 1.5" J Hooks

Read and understand instructions before attempting installation

Step 1

Test fit the grille over the factory grille. Use a slotted screwdriver to remove the fasteners holding the plastic radiator cover. Remove the six 10mm and two 7mm bolts along the top of the grille.

Step 2

Place a block of wood or something similar between the top of the grille and the metal core support. This will allow access to the back of the grille. Slide the u-nuts onto the J hooks. Insert the machine screws into the tabs on the grille. Thread the short J hooks on the top screws and the longer J hooks on the bottom. Center the billet over the factory grille. Wrap the J hooks around the plastic bars and tighten the screws.

Step 3

Align the grille assembly into the core support and fasten the bolts. Re-install the radiator cover.
Thank you for purchasing a T-Rex Billet Grille. 3/24/06

