

21908
08-10 TOYOTA
COROLLA



21908
08-10 TOYOTA
COROLLA

08-10 TOYOTA COROLLA

Billet Grille

TOOLS REQUIRED:

Phillips Screwdriver
8mm Socket and Ratchet

PARTS LIST

(4) Washers
(4) 6/32 Nylon Lock Nuts
(4) 1 1/2" Phillip Screws
(1) Billet Grille

Step 1

PLEASE READ AND UNDERSTAND ALL INSTRUCTIONS BEFORE ATTEMPTING INSTALLATION. Take the billet grille and insert it into the factory grille opening. (Fig 1)

Step 2

From the front of the billet grille insert the 1 1/2" phillip screws into the small square brackets that are welded onto the back of the billet grille. (Fig 2 & 3)

Step 3

You will need a helper to hold the billet grille in the factory grille opening. From underneath the vehicle reach up behind area and find the screws on the backside of the billet grille. Put a washer and 6/32 Nylon Lock Nut on the screw and tighten it with a 8mm socket and ratchet while having your helper hold the screw secure with a phillips screwdriver. Make sure the washer is crossing over the black plastic ribs to keep the billet grille from falling out. Repeat this on the remaining screws. (Fig 4)

