

25076

99-02 CHEVY
SILVERADO
BUMPER TOP PAD
BILLET INSERT



25076

99-02 CHEVY
SILVERADO
BUMPER TOP PAD
BILLET INSERT

99-02 SILVERADO, 00-03 SUBURBAN & TAHOE
1 PC; BUMPER TOP PAD BILLET INSERT

Tools Required:

Pliers

Hardware / Parts Included:

1 - Billet Insert (3 bars)

Read and understand instructions before attempting installation

Step 1.

Note the four tabs on the rear of each billet. These tabs will apply pressure to the rear of the top pad to hold the billets in place. It may be necessary to slightly bend these tabs out using your hands or pliers.

Step 2.

Use masking tape around each opening if the bumper pad is painted. Place one billet with the top tabs in first; Then apply even pressure at each tab along the lower of the billet till it snaps in the bumper pad. Repeat this on the other insert.

Step 3.

Installation is now complete. *Thank you for purchasing a T-Rex Billet Grille.*