





04-08 NISSAN TITAN / ARMADA

Tools Required:

Phillip Screw Driver Drill 1/16" Drill Bit

Hardware / Parts Included:

- 2 Fog Light Insert (Passenger & Driver Side)
- 4 #8 x 1 Screw (#6 Head)

Read and understand instructions before attempting installation

<u>Step 1</u>

Center the (horizontal or vertical) into the opening. Mark the two mounting holes on fog light area where grille tabs will be aligned for installation. Drill a 1/16" pilot hole for each location. Use the screws to secure the insert. Repeat installation of other side; installation complete. **Thank you for purchasing a** *T-REX BILLET GRILLE*.