

54290

03-07 H2

HUMMER



54290

03-07 H2

HUMMER

1 PC UPPER CLASS SERIES GRILLE

03-07 HUMMER H2 SUV & SUT

Recommended Tools:

3/8 Wrench or Nut Driver
Jigsaw & Die Grinder or Dremel Tool
Files / Sandpaper
Masking Tape
5/16" Socket / Wrench


Parts List / Hardware:

1 Billet Inserts
8 6-32 Nylon Lock Nuts & Washers
8 135' Flange Brackets

Read and understand instructions before attempting installation

Step 1

Open the hood and remove the grille. Place the grille face up on a work-table. The six chrome vertical bars in the center of the grille must be cut from the grille. The billet has a large perimeter that will cover your cuts. Apply a strip of masking tape along the top and bottom of the grille; approximately 7 1/4" apart. Make the two cuts along the top and bottom from the front. Test fit the billet in place. Now cut the remaining plastic from the back of the grille; make your cut approximately 1/4" from the back of the grille. This will leave a small lip around the back of the grille.



Step 2

File or sand your cuts smooth. Center the grille; install a washer, flange and nut onto each stud. Tighten the nuts until the grille is held in place. Re-install the grille assembly back onto the vehicle. ***Thank you for purchasing your T-Rex billet grille. 3/1/07***