

51794

54794

11-13 INFINITI QX56



51794

54794

11-13 INFINITI QX56

11-13 INFINITI QX56

Side Vents

Install time: 25 Mins.

TOOLS REQUIRED:

- Plastic Prybar
- Fishing Line
- Socket & Ratchet set

PARTS LIST:

- (2) Side Vents

PLEASE READ AND UNDERSTAND ALL INSTRUCTIONS BEFORE ATTEMPTING INSTALLATION.

- With a Fishing Line, Start going behind the Side Vent to Loosen it up a bit. (Fig. 1)
- Use a Plastic Prybar or anything flat to start remove the Side Vent Carefully. (Fig. 2)
- Remove the Factory Side Vent. (Fig. 3)
- Loosen the Nylon Lock Nut so you can move the Bracket. (Fig. 4)
- Place the Side Vent through the Factory Opening. (Fig. 5)
- From Behind the Side Vent, Have the Bracket Latch onto the Factory Fender and Tighten the Nylon Lock Nut (Place back the Bracket onto the Threaded Stud to Lock it in Place.) (Fig. 6)

INSTALLATION COMPLETE

