

55183

**02-06 CADILLAC
ESCALADE**



55183

**02-06 CADILLAC
ESCALADE**

02-06 Cadillac Escalade UPPER CLASS SERIES MESH BUMPER

Tools Required:

Slotted Screwdriver
1/2" Socket
14mm Socket
Drill & 1/4" Drill Bit

Parts List:

2 Upper Class Grilles (Right & Left)
4 1/2" x 1/2" L Brackets
4 6/32 Nylon Lock Nuts

Read and understand instructions before attempting installation

Step 1

Use a 14mm socket to remove the tow hooks from the vehicle. Test fit each grille in the bumper openings. Remove the black plastic covers from each insert opening. Center the new insert into the opening. From the backside of the bumper; place an L Bracket and nylon lock nut onto each stud (1). Making sure the insert is centered; tighten the hardware. Repeat this on the other side.



Thank you for purchasing a T-Rex billet grille.
05/14/08