



2012 NISSAN VERSA
Upper Class Bumper Mesh Grille
Install time: 25 Mins.

TOOLS REQUIRED:

Socket Wrench
Plastic Prybar

PARTS LIST:

(1) Mesh Grille
(4) 1/2 L-Brackets
(4) 6/32 Nylon Lock Nuts

PLEASE READ AND UNDERSTAND ALL INSTRUCTIONS BEFORE ATTEMPTING INSTALLATION.

- Remove 5 Clips along the top of the Grille Shell. (Fig.1)
 - Unclip 8 Clips along the Bottom of the Factory Grille to Remove.
 - Remove 3 Clips to remove Plastic Cover that is on the right side of vehicle. (Fig. 2)
 - Remove 5 Bolts from behind the Grille. (Fig. 3)
 - Unclip the Grille along the bottom and remove. (Fig. 4)
 - Place the Mesh Bumper through the Factory Bumper Opening. (Fig. 5)
 - Unclip the Plastic flap and move it to the side. (Fig. 6)
 - From Behind the Grille, insert an L-Bracket and Thread with 6/32 Nylon Lock Nut. (Fig. 7)
- Repeat for remaining screws.

Installation Complete

