

6710840 6710841
04-08 CHEVY
KODIAK



6710840 6710841
04-08 CHEVY
KODIAK

04-08 CHEVY KODIAK

1 Pc. Side Vent

TOOLS REQUIRED

Socket and Ratchet Set
Phillips/Slotted Screwdrivers
Allen Wrench Set
Drill and Bits
Vise Grips
Grinding Wheel or Jigsaw

PARTS LIST GRILLE

(3) #8 X 1" Screws
(3) #8 Nut Plates
(1) Mesh Vent Grille

PLEASE READ AND UNDERSTAND ALL INSTRUCTIONS BEFORE INSTALLATION. Auto makers offer varied models to each vehicle and occasionally manufacture more than one body style of the same model. To assure your part is correct; our tech department can be contacted at tech@trexbillet.com to verify fitment or assist with tech questions. All other inquires can be directed to info@trexbillet.com. In the event you do not have internet access please call 1-800-287-5900.

Step 1

Remove the factory side vent housing from the vehicle. Cut out the center part of the factory side vent housing and sand smooth. Insert the mesh vent insert into the vent housing and press it in flush. Use vise grips to hold the vent grille into the housing by clamping the tabs on the vent insert to the lip in the vent housing (Fig 1). Drill a small hole through the tabs on the vent insert and through the lip on the vent housing (Fig 2). Using the supplied screws and nut plates secure the vent insert into the housing (Fig 3). Reinstall the vent housing with the grille insert installed into the vehicle using the factory hardware. Installation complete.

