


INSTRUCTION MANUAL CAT-BACK STAINLESS SINGLE EXHAUST 00-06 JEEP WRANGLER TJ & RUBICON 2.5L-4.0L 4WD PART #617700



ITEM	PART #	QTY	DESCRIPTION
A	13215S-B	1	STAINLESS SUPERFLOW MUFFLER W/ FLGE #GP-102
В	931-700703S	1	2-1/4" STAINLESS OVERAXLE TAILPIPE
С	500370	1	3" STAINLESS TIP
D	5756	1	2-1/4" CLAMP
E	BO-1020	1	BOLT KIT FOR MUFFLER FLANGE

EXIT IS STRAIGHT OUT THE BACK. FLANGE CONNECTION TO THE CONVERTER.

*Will not fit w/ a Long Travel Lift Kit.

Thank you for purchasing our GIBSON EXHAUST SYSTEM for your vehicle. If you need further assistance, please do not hesitate to call our Technical Department at (800) 528-3044, Monday through Friday, 8:00 am to 5:00 pm 0706

INSTALLATION INSTRUCTIONS

WHEN INSTALLING THIS EXHAUST SYSTM, MAKE SURE TO USE PROPER SAFETY PRECAUTIONS. USE JACK STANDS WHEN UNDER THE TRUCK, BLOCK TIRES AND USE SAFETY GLASSES AND GLOVES. **DO NOT WORK WITH HOT PIPES!**

SUGGESTED TOOLS:

15MM SOCKET, 9/16" SOCKET, ½" WRENCH, ½" SOCKET, HACKSAW, WD-40



LAY OUT THE GIBSON EXHAUST ON THE FLOOR SO IT LOOKS LIKE THE DRAWING AND COMPARE IT TO THE MANUAL, TO REMOVE THE STOCK EXHAUST CUT OFF TAILPIPE JUST BEHIND THE MUFFLER THEN REMOVE MUFFLER FROM 2- BOLT FLANGE JUST IN FRONT OF MUFFLER, LEAVE ALL RUBBER GROMMETS IN PLACE. USE WD-40 TO AID IN REMOVAL OF EXHAUST AND HANGERS.





INSTALL THE OVERAXLE TAILPIPE #B INTO THE MUFFLER 1 ½" TO 2". SECURE TO THE MUFFLER USING CLAMP #D. DO NOT TIGHTEN. INSERT WELDED HANGERS INTO RUBBER GROMMETS. NOTE, SHORT END OF OVER AXLE PIPE INSERTS INTO MUFFLER.



ATTACH MUFFLER
ASSEMBLY #A ONTO YOUR
EXISTING STOCK FLANGE.
USE BOLT KIT # E TO
SECURE TO FLANGE. USE A
JACK STAND TO SUPPORT
THE MUFFLER.



INSTALL STAINLESS
STEEL TIP. CLAMP
DOWN. WHEN YOU HAVE
EVERYTHING IN PLACE,
FIRMLY TIGHTEN ALL
BOLTS AND CLAMP
DOWN SECURELY. TO
CLEAN STAINLESS TIP,
USE A SCOTCH BRITE
PAD AND ANY
STAINLESS STEEL OR
ALUMINUM CLEANER.

MAKE SURE YOU HAVE A 1" CLEARANCE ON ALL BRAKE LINES, FUEL LINES, SHOCKS, TIRES, ETC.