

# ***Installation Instructions for 511120 & 511121 GM LT & LS Silicone Hose Kit***

## **Installation Instructions:**

1. Remove the lower radiator hose from the water pump and let drain.
2. Remove the lower radiator hose from the vehicle.
3. Match up your new lower radiator hose to the original and install your new lower radiator hose onto the vehicle.
4. Remove the upper radiator hose from the radiator and let drain.
5. Remove the upper radiator hose from the vehicle.
6. Match up your new upper radiator hose to the original and install your new upper radiator hose onto the vehicle.
7. Remove the two front heater core hoses from the water pump and let drain.
8. Remove the two front heater core hoses from the vehicle.
9. Match up your new front heater core hoses to the originals by cutting/trimming one end of the smaller two hoses and install your new front heater core hoses onto the vehicle.
10. Remove the two rear heater core hoses from the rear of the engine and let drain.
11. Remove the two rear heater core hoses from the vehicle.
12. Match up your two new rear heater core hoses to the originals by cutting/trimming one end of the smaller two hoses and install your new rear heater core hoses onto the vehicle.
13. Refer to the vehicle service and repair manual for filling of the coolant system.



**1-800-345-4545 [jeps.com](http://jeps.com)**