

Installation Instructions for 68091, 68093, 68097 Dragster Wheel Centers

Note: For use on Weld Racing 786 Magnum Drag 2.0 and 788 AlumaStar 2.0 series wheels.

Installation Instructions:

1. Use one drop of red LOC-TITE on each bolt and torque to 24 ft/lbs. in a "star" pattern as shown below.

