



## JET POWERTECH PULLEYS

PART # 90105

1. Remove existing belt and pulleys. Remove spacer ring from behind factory alternator pulley.
2. Install new pulleys. Use Loctite Thread Lock #2 + 2 or equivalent to secure bolts.
3. Install Gates (or equivalent) belt as follows (with a/c):

88-95 K060915

88-89 w/smog pump K060990

90-95 w/smog pump K060930

96-00 4.3L,5.0L,5.7L, K060935

90-96 Astro/Safari Van no smog K060960

add 6" to belt for smog